

# Woven Fabrics Hooping Guide



For all of the following fabrics you will **70/10 Sharp needles**.

**Basic Dress Shirts** - Use 2 layers of 1.5 oz crisp tearaway backing-topping on the top –Topping to keep dirt & Oil from dripping. Topping protects fabric



**Denim Shirts – Ladies Cotton Shirts** - 2 layers of 1.5 oz Crisp Tearaway backing. If fabric wants to pucker-use 1 layer of 3 oz. Crisp Tearaway



**All Items below** - use 2 layers of 1.5 oz Crisp Tearaway backing

**Brief Bags**  
**Cinch Bags**  
**Tote Bags**



**Woven Performance Fabrics**  
**Woven Camp Shirts**  
**Work Shirts**



**Woven Jackets**  
**Carhart Jackets**  
**Aprons**



**Caps**-Use 1 layer of crisp 3 oz. cap backing. You may need to change to 75/11 needle, but try the 70/10 needle first!